


* Installation (Please follow by the introduction below)


- 1.close the door, folding installation template a right angle by 90° .
Make the sign on the door which will be installed use by installation template.
- 2.based on drilled hole, assembling all parts as below picture and fixing by the screws.

(Install order)




⚠ "Striker" Installation notes

- (1) striker installed at the left side (internal as the benchmark)



5.0-6.0mm distance maintain

- (2) striker installed at the right side (internal as the benchmark)



5.0-6.0mm distance maintain

⚠ Measure the distance between striker and interior of product about 5-6mm, then tighten the screw. (The distance change will affect the Auto locking function)

Keep 5-6mm distances between interior unit and striker otherwise, it may cause the installation unsuccessful.

- 1 Putting batteries and press the password in order to check the digital door lock does work properly.
- 2 Check "opening and dosing" door mode working smoothly.
- 3 If it works unmoral, please regulate the striker upper or down.
- 4 "Dead bolt" must hit the striker.
- 5 Check the door does dose automatically
- 6 Check the door can be opened by electro-key.

